


## Attenuation Measurement

$$\underline{\gamma} = \underline{\alpha} + j \underline{\beta}$$

(dB)


$$\text{Attenuation} = 10 \log_{10} \frac{P_{in}}{P_{out}}$$






Set up ① Power ratio method







set up ② Power ratio method







Attenuation measurement:

- (i) microwave components & devices always almost provide some degree of attenuation.
- (ii) Attenuation is defined as the ratio of input power to the output power and is normally expressed in decibels.

i.e.

$$\text{Attenuation} = 10 \log_{10} \left( \frac{P_{in}}{P_{out}} \right) \text{ in dB}$$

where  $P_{in}$  = input power ;  $P_{out}$  = o/p power.

The attenuation can be measured by two methods.

- (i) power ratio method      (ii) RF substitution method.

A) power ratio method:

It involves measuring powers  $P_1$  &  $P_2$  without & with

(ii) the d  
the power  
crystal  
calculated  
network

B) RF s

(i) In

This method involves measuring powers  $P_1$  &  $P_2$  without & with device whose attenuation is to be measured. The ratio of  $\frac{P_1}{P_2}$  expressed in decibels gives attenuation.




Fig: set up - power ratio method

expressed in decibels gives attenuation.





Fig: set up - power ratio method



(ii)

(iii)

wl

(ii) The drawback of this method is the power positions indicated by the power meter will lie on the non-linear characteristics or crystal diode. Due to this the powers measured & attenuation calculated will not be accurate particularly if the attenuation of network is large & if the input power is low.




Fig: Square law characteristic

of crystal diode.

range of the input power is low.





Fig: Square law characteristics of crystal diode.

### B) RF substitution method:

- In this method, we measure attenuation at a single power position.






Fig: setup 1 - RF substitution method

In this method, the power 'P' is measured by placing the device whose attenuation is to be measured as shown in setup 1.

'P in watts'





Fig: Setup 2 - RF substitution method

Setup 2, the device is measured by a precision calibrated attenuator

Fig: Set up

- ii) In this method, the power 'P' is measured by placing the device whose attenuation is to be measured as shown in setup 1.

'P in watts'

Fig: Setup 2 - RF substitution method

- iii) In setup 2, the device is replaced by a precision calibrated attenuator which can be adjusted to obtain the same power 'P' as measured in set up 1. Under this condition, the attenuation read on the precision attenuator would be the required answer.